




Cat. No. 63-1052

Soft-Grip Laser Pointer



Your RadioShack Soft-Grip Laser Pointer lets you use laser light to point to an object. You can use the pointer on a board or projection screen at a meeting, lecture, class, or seminar.

Your laser pointer, usable from distances up to 400 yards away, eliminates needless movement so you can keep your attention on your audience. Its lightweight plastic construction makes it easier to handle than wood or steel pointers, and it has a handy clip.

Warnings:

- Never point the laser at anyone.
- Never look directly into the laser beam.
- Keep the laser pointer away from children.
- Follow the instructions on the pointer's danger label.
- Use of controls or adjustments, or the performance of procedures other than specified herein, can result in hazardous radiation exposure.



INSTALLING BATTERIES

Your laser pointer uses two AAAA batteries. For the best results, we recommend alkaline batteries, available at your local RadioShack store.

Caution: Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.

1. Remove the battery compartment cap by turning it counterclockwise.
2. Insert both batteries with the negative (–) sides toward the lens opening.
3. Replace the cap.

Replace both batteries when the beam dims.

USING THE POINTER

Hold down the button to shine the laser beam.

Release the button to turn off the laser.

© 1999 Tandy Corporation.
All Rights Reserved.

RadioShack is a registered trademark used by Tandy Corporation.

